INSTALLER PROGRAMMABLE FUNCTIONS

After completing all the electrical connections, the installer can personalise the system considering the characteristics of the vehicle and the customer's requirements.

Each function can be programmed only by using the remote control as follows:

➢ Disarm the alarm using the remote control.

➢ Open the door on the driver's side and turn the ignition key ON.

➢ Press and keep pressing the button "B" of the remote control, turn the ignition key OFF and release the button.

➢ The red LED on the dashboard will turn on and remain on and you will hear an audible chirp at the same time. The programming procedure is activated from this point on.

➢ Choose and activate the required function by pressing one of the two buttons on the remote control as many times as required.

➢ Press button "A" or "B" the number of times indicated in the function code table (example: if you want to deactivate the ACCIDENTAL ANTI-DISARMING function, press button "B" of the remote control 6 times). The LED will turn off each time the remote control button is pressed. After pressing the remote control button the number of times required, wait 2 seconds for programming to be confirmed by a brief audible chirp. After this first programming operation you can perform another one by carefully following what is indicated in the "programming table".

➢ To end the programming session, turn the ignition key ON or wait 30 seconds. In both cases, the red LED on the dashboard will immediately turn off.

PROGRAMMING TABLE

For additional information about functions read the SPECIAL PROGRAMMABLE/INSTALLATION FUNCTIONS page 14.

FUNCT. CODE	PROGRAMMABLE FUNCTION	PRESSING BUTTON "A" OF THE REMOTE CONTROL	PRESSING BUTTON "B" OF THE REMOTE CONTROL
1	ENABLE/DISABLE AUDIBLE CHIRP	ON	OFF
2	NOT USED		
3	POWER LOCKING SYSTEM LOCKING TIME	0,8 sec.	3 sec.
4	COMFORT LOCKING (25 sec.)	ON	OFF
5	INTERNAL RELAY PASSIVE ARMING 212 OFF – 213 ON	ON	OFF
6	ACCIDENTAL DISARMING	ON	OFF
7	PASSIVE ARMING	ON	OFF
8	BUTTON 3 FUNCTION	PARKING/COURTESY LIGHTS	BOOT OPENING
9	NOT USED		
10	NOT USED		
11	SAFETY LOCK	ON	OFF
12	ADDITIONAL SENSOR	ADDITIONAL SENSOR	ADDITIONAL SENSOR + ULTRASONIC
13	NOT USED		
15	BONNET CONTACT INPUT	POSITIVE	NEGATIVE
16	DOOR CONTACT INPUT	POSITIVE	NEGATIVE
17	NOT USED		

The function in the boxes with the grey background are programmed by the manufacturer.

1 audible chirp to confirm programming

2 audible chirps to confirm programming

14